REPORT NUMBER 114-GTL-10-010

SAFETY COMPLIANCE TESTING FOR FMVSS NO. 114 THEFT PROTECTION

FORD MOTOR CO. 2010 FORD TAURUS, PASSENGER CAR NHTSA NO. CA0210

GENERAL TESTING LABORATORIES, INC. 1623 LEEDSTOWN ROAD COLONIAL BEACH, VIRGINIA 22443



April 14, 2010

FINAL REPORT

PREPARED FOR

U. S. DEPARTMENT OF TRANSPORTATION NATIONAL HIGHWAY TRAFFIC SAFETY ADMINISTRATION ENFORCEMENT OFFICE OF VEHICLE SAFETY COMPLIANCE 1200 NEW JERSEY AVE., SE WASHINGTON, D.C. 20590 This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturers' names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products or manufacturers.

| Prepared By: |
|--------------|
| |

Approved By:

Approval Date: 04/14/10

FINAL REPORT ACCEPTANCE BY OVSC:

Accepted By: 1 Acceptance Date:

Technical Report Documentation Page

| 1. Report No.2. Government Accession No.3. Recipient's Catalog No.114-GTL-10-010N/AN/A4. Title and Subtitle5. Report Date | | |
|---|--|--|
| | | |
| 4. Title and Subtitle 5. Report Date | | |
| | | |
| Final Report of FMVSS 114 Compliance Testing of a April 14, 2010 | | |
| 2010 FORD TAURUS PASSENGER CAR 6. Performing Organ. Code | | |
| NHTSA No. CA0210 GTL | | |
| 7. Author(s) 8. Performing Organ. Rep# | | |
| Grant Farrand, Project Engineer GTL-DOT-10-114-010 | | |
| Debbie Messick, Project Manager | | |
| 9. Performing Organization Name and Address 10. Work Unit No. (TRAIS) | | |
| General Testing Laboratories, Inc. N/A | | |
| 1623 Leedstown Road 11. Contract or Grant No. | | |
| Colonial Beach, Va 22443 DTNH22-06-C-00032 | | |
| 12. Sponsoring Agency Name and Address13. Type of Report and Period | | |
| U.S. Department of Transportation Covered | | |
| National Highway Traffic Safety Admin. Enforcement Final Test Report | | |
| Office of Vehicle Safety Compliance (NVS-220) March 29, 2010 | | |
| 1200 New Jersey Ave., S.E., 14. Sponsoring Agency Code | | |
| Washington, DC 20590 NVS-221 | | |
| 15. Supplementary Notes | | |
| | | |
| 16. Abstract | | |
| Compliance tests were conducted on the subject 2010 Ford Taurus 4-door Passenger Car | | |
| in accordance with the specifications of the Office of Vehicle Safety Compliance Test | | |
| Procedure No. TP-114-03-DRAFT-GTL-REVC for the determination of FMVSS 114 | | |
| compliance. | | |
| | | |
| Test failures identified were as follows: | | |
| None | | |
| | | |
| 17. Key Words 18. Distribution Statement | | |
| Compliance Testing Copies of this report are available from | | |
| Safety Engineering NHTSA Technical Information Services (| | |
| FMVSS 114 Room W45-212 (NPO-411) | | |
| 1200 New Jersey Ave., S.E. | | |
| Washington, DC 20590 | | |
| Telephone No. (202) 366-4947 10. Security Classif (of this report) 21. No. of Pages 22. Price | | |
| 19. Security Classif. (of this report)21. No. of Pages22. PriceUNCLASSIFIED28 | | |
| 20. Security Classif. (of this page) | | |
| UNCLASSIFIED | | |
| | | |

Form DOT F 1700.7 (8-72)

TABLE OF CONTENTS

PAGE SECTION 1. Purpose of Compliance Test 1 2. Test Procedure and Summary of Results 2 3. Test Data 3 4. Test Equipment List 13 5. Photographs 14 5.1 ³/₄ Frontal View from Left Side of Vehicle 5.2 Vehicle Certification Label 5.3 Vehicle Tire Information Label 5.4 Close-up View of Electronic Ignition Key Device

- 5.5 Start/Stop Button on Dash
- 5.6 Electronic Key Device Back-up Slot
- 5.7 Electronic Key Device in Back-up Slot
- 5.8 No Key Detected Warning
- 5.9 Transmission Gear Selection Control
- 5.10 Gear Selector Release Tool

PURPOSE OF COMPLIANCE TEST

1.0 PURPOSE OF TEST

A model year 2010 Ford Taurus Passenger Car was subjected to Federal Motor Vehicle Safety Standard (FMVSS) No. 114 testing to determine if the vehicle was in compliance with the requirements of the standard. FMVSS 114 specifies requirements to decrease the likelihood that a vehicle is stolen, or accidentally set in motion.

- 1.1 The test vehicle was a 2010 Ford Taurus Passenger Car. The vehicle was identified as follows:
 - A. Vehicle Identification Number: 1FAHP2EW5AG143449
 - B. NHTSA No.: CA0210
 - C. Manufacturer: FORD MOTOR CO.
 - D. Manufacture Date: 01/10
 - E. Color: Gold Metallic
- 1.2 TEST DATE

The test vehicle was subjected to FMVSS No. 114 testing on March 29, 2010.

TEST PROCEDURE AND SUMMARY OF RESULTS

2.0 <u>TEST PROCEDURE</u>

All tests were conducted in accordance with NHTSA, Office of Vehicle Safety Compliance (OVSC) Laboratory Procedure TP-114-03-DRAFT-GTL-REVC and General Testing Laboratories, Inc. (GTL) Test Procedure, TP-114-03-Draft, "Theft Protection and Rollaway Prevention".

2.1 <u>SUMMARY OF RESULTS</u>

Test data indicate the FMVSS 114 requirements appear to have been satisfied. All test data resulting from the tests were recorded on test data sheets in Section 3.

TEST DATA

3.0 TEST RESULTS

The following data sheets document the results of FMVSS 114 testing on the 2010 Ford Taurus.

FMVSS 114, THEFT PROTECTION DATA SHEET 1 – VEHICLE IDENTIFICATION

 TEST DATE:
 03/29/10

 CONTRACT:
 DTNH22-06-C-00032

 VIN:
 1FAHP2EW5AG143449

LAB.: <u>General Testing Laboratories</u> VEH. NHTSA NO.: <u>CA0210</u> BUILD DATE: 01/10

MY/MAKE/MODEL/BODY STYLE: 2010 Ford Taurus

| TRANSMISSION TYPE: Automatic <u>X</u> ; Manual; Other (describe: |) |
|--|---|
| DRIVE TRAIN TYPE: Front Wheel <u>X</u> ; Rear Wheel; 4-Wheel | |
| FUEL TANK LEVEL: <u>100</u> (% OF max.) MILEAGE: <u>63.2</u> | • |
| VEHICLE STARTING SYSTEM: | |
| Location of the starting system: Located on Dash to the Right Side of Steering Column | - |
| Selectable settings: Off, Accessory, On, Start | - |
| Explain how the system is activated: The system is activated when the engine start button is pressed while the Electronic | |

Intelligent Access (IA) is present inside the vehicle.

<u>KEY</u>

Description of the key: Electronic Key FOB with embedded code

STARTING SYSTEM ACTIVATION

Describe how the key is inserted into the starting system: <u>The system is activated when the engine start button is pressed while the Electronic</u> <u>Intelligent Access (IA) is present inside the vehicle.</u>

Describe how the key is used to activate the starting system: <u>The Electronic Key is inserted into the ignition system by an encrypted radio frequency</u> where the key is electronically stored in memory.

Describe how the key is removed from the starting system:

The Electronic Key is removed (purged) from the starting system when the following conditions have been met: (1)The transmission has been shifted to "park", (2) The engine has been turned off by pressing the engine stop switch and (3) a valid intelligent access key is present in the vehicle.

FMVSS 114, THEFT PROTECTION DATA SHEET 1 continued

| GEAR SELECTION CONTROL |
|--|
| Describe the gear selection control: Center Console Mounted Gear Selector. |
| Describe how the gear selection control is activated: Depress on Brake Pedal then move gear selector to desired position. |
| Describe all of the selectable settings: Park, Reverse, Neutral, Drive, Manual |
| IMMOBILIZER |
| Is the vehicle equipped with an immobilizer YES X NO |
| Describe the immobilizer device and how it prevents vehicle theft (if equipped): The Passive Anti Theft System (PATS) prevents the engine from being started unless A coded key is used that is programmed to the vehicle. The immobilizer requires multiple modules to confirm the correct key is present. |
| OPTIONAL RELEASE DEVICES |
| Describe if the vehicle is equipped with optional release devices: Yes |
| OPTIONAL RELEASE DEVICES: |
| Key Removal Gear Selection ControlX None Other |
| VEHICLE FLUIDS |
| Check all vehicle fluids and adjust to the proper levels for operation: Full |
| VEHICLE TIRE PLACARD INFORMATION |
| Vehicle Mfg. Recommended Tire Inflation Pressure (kPa): Front <u>220</u> Rear <u>220</u> |
| TIRE INFLATION PRESSURES: |
| Measured (kPa): LF <u>220</u> LR <u>220</u> RF <u>220</u> RR <u>220</u> |
| WEIGHT |
| Vehicle Curb Weight(kg): <u>1835</u> Weight of Driver (kg): <u>91</u> (target = 91kg) |

FMVSS 114, THEFT PROTECTION DATA SHEET 2

| REQUIREMENT S5.1.1 | | FAIL |
|--|----------|----------|
| Engine cannot be started without using the key <u>X</u> YesNo | Х | |
| With key removed, steering wheel locks: Yes: <u>No: X</u> | | |
| Identify locking position(s) on wheel using arrow(s) | 278 0 86 | |
| | | , |
| Clockwise: (degrees) Counterclockwise: (degrees) | | <u> </u> |
| Key removal prevents forward self-mobility: Yes: X No |): | |
| If yes describe: Vehicle will not start without key. | | - |
| When key is removed from the starting system, starting of the engine or motor and either steering or self mobility is prevented. YES | X | |

REMARKS:

FMVSS 114, THEFT PROTECTION DATA SHEET 2 continued

| REQUIREMENT S5.1.3 | PASS | FAIL |
|---|------|------|
| An audible warning is activated whenever the key is in any starting system position with the exception of "on" and "start" and the door closest to the driver's designated seating position is opened. Yes <u>X</u> No | x | |
| Identify ALL key/starting system position setting: OFF, ACCESSORY, ON, START | | |

| REQUIREMENT S5.1.4 | PASS | FAIL |
|---|------|------|
| With the vehicle engine or motor shut down and the transmission gear selection control in any position other than "park"; | x | |
| The steering wheel can rotate without locking? Yes X No | | |
| NOTE: Engine cannot be turned off by push button if gear selector is not in | | |
| the park position. | | |
| The vehicle is free to roll forward? Yes X No | x | |

REMARKS: The Electronic Key is removed (purged) from the starting system when the following conditions have been met; (1)Transmission shifted to the "park" position, (2)The engine has been turned off by pressing the engine stop switch and (3) a valid intelligent access key is present in the vehicle.

| RECORDED BY: | G. Farrand | |
|--------------|------------|--|
| APPROVED BY: | D. Messick | |

DATE: <u>03/29/10</u>

FMVSS 114, ROLLAWAY PREVENTION DATA SHEET 3 (for vehicles equipped with transmission with a "park" position)

TEST DATE: 03/29/10

VEH. NHTSA NO.: CA0210

| REQUIREMENT S5.2.1 | PASS | FAIL |
|--|------|------|
| The starting system prevents key removal in ALL gear selection control positions except "park". Yes <u>X</u> No | | |
| Can the gear selection control be placed between each gear selection position and will it remain there without assistance? Yes No_X | Х | |
| If yes, can the key be removed from the starting system? Yes No | | |
| If the key can be removed from the vehicle starting system when the gear selection control is not locked in "park", a mechanism shall exist which, upon key removal, the vehicle transmission or gear selection control shall become locked in "park" as the direct result of removing the key. If such a mechanism exists, describe the mechanism and its function: | | |

| REQUIREMENT S5.2.2 | PASS | FAIL |
|--|------|------|
| The gear selection control is locked in the "park" position when the key is removed from the starting system. Yes <u>X</u> No | х | |

REMARKS: If the Electronic Intelligent Access (IA) key is not present inside the vehicle when the engine is shut off, the fast restart feature allows the driver to restart the vehicle for up to 20 seconds even though the IA key is not present.

| REQUIREMENT S5.2.3 | PASS | FAIL |
|--|------|------|
| ELECTRICAL FAILURE (Battery Discharge) | | |
| In the event of an electrical failure, key removal from the starting system when the transmission or gear selection control is not locked in "park" is permitted". Yes X No | | |
| The vehicle is equipped with an override device that permits key removal from the starting system when the transmission or gear selection control is not locked in "park". Yes No_X | | |
| If yes, select the type of override device equipped: Opaque Cover No Cover Describe the override device design and mode of activation (if equipped): | N/A | |
| FILL IN THE SECTION BELOW THAT APPLIES: | | |
| OVERRIDE WITH AN OPAQUE COVER: | | |
| The opaque surface cover prevents sight of and use of override device. Yes No | | |
| The opaque surface cover can only be removed by using a screwdriver or other tool. Yes No | N/A | |
| As a direct result of removing the key from starting system, the following is prevented: Steering or Self-Mobility | | |
| OVERRIDE WITH NO COVER | | |
| The override device requires the use of a tool to activate. Yes No | | |
| Simultaneous activation of the override device and removal of key from starting system is required. YesNo | N/A | |
| As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility | | |

REMARKS:

| REQUIREMENT S5.2.4 | | FAIL |
|---|-----|------|
| GEAR SELECTION CONTROL OVERRIDE DEVICE | | |
| The vehicle is equipped with an override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. Yes X No | | |
| If yes, select the type of override device that is equipped: Override operated with a: Key Opaque Cover X_ No Cover | Х | |
| Describe the override device design and mode of activation (if equipped): Push button release activated by a special wrench supplied in tool kit. | | |
| FILL IN THE SECTION BELOW THAT APPLIES: | | |
| OVERRIDE OPERATED WITH KEY: | | |
| The key is required to operate the override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. | N/A | |
| OVERRIDE WITH AN OPAQUE COVER | | |
| The opaque surface cover prevents sight of and use of override device. Yes X No | | |
| The opaque surface cover can only be removed by using a screwdriver or other tool. Yes X No | Х | |
| As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility X | | |
| OVERRIDE WITH NO COVER | | |
| The override device requires the use of a tool to operate. Yes No | | |
| Simultaneous activation of the override device and removal of key from starting system is required. Yes No | N/A | |
| As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility | | |
| | | |

REMARKS: Gear Selection control override device with an opaque cover.

| REQUIREMENTS S5.2.5 | PASS | FAIL |
|--|------|----------|
| VEHICLE FACING UPHILL ON 10% GRADE | | |
| With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake. | | see note |
| Test grade: <u>15</u> % (9% to 15%) Measured movement: <u>46</u> mm (150mm maximum) | Х | |
| NOTE: Repeat procedure if vehicle fails on grade in excess of 10%. | | |
| Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum) | | |
| VEHICLE FACING DOWNHILL ON 10% GRADE | | |
| With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake. | | |
| Test grade: <u>15</u> % (9% to 15%) Measured movement: <u>50</u> mm (150mm maximum) | х | |
| NOTE: Repeat procedure if vehicle fails on grade in excess of 10%. | | |
| Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum) | | |
| | | |

REMARKS:

| REQUIREMENTS S5.3 | PASS | FAIL |
|---|--|------|
| VEHICLE FACING UPHILL ON 10% GRADE | | |
| With the key in the "off" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X | <u> </u> | |
| With the key in the "acc" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X | <u> </u> | |
| With the key in the "on" position (engine off), the transmission will shift out of "park" without the service brake being applied. Yes No_X | <u> </u> | |
| With the key in the "start" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X | <u> X </u> | |
| With the key in the "other" position (please specify), the transmission will shift out of "park" without the service brake being applied. Yes No | <u>N/A</u> | |
| Does the key stay between starting system positions without being held by operator? Yes No_X If so, please describe. | <u>x</u> | |
| Brake force readings (force required to allow the transmission to shift out of "park"): | | |
| The vehicle is equipped with adjustable pedals: Yes <u>X</u> No | | |
| Fore Position: Aft Position (if applicable) | | |
| Reading 1 4.7 N Reading 1 4.4 N Reading 2 4.4 N Reading 2 3.1 N Reading 3 4.8 N Reading 3 3.1 N Reading 4 4.7 N Reading 4 4.1 N Reading 5 4.6 N Reading 5 4.1 N Avg. 4.64 N Avg. 3.76 N | <u>x</u> | |

REMARKS:

| RECORDED BY: | G. Farrand | DATE: | 03/29/10 |
|--------------|------------|-------|----------|
| APPROVED BY: | D. Messick | | |

SECTION 4 TEST EQUIPMENT LIST

| ITEM | MFR | MODEL | S/N | CAL. PERIOD | DATE OF NEXT CALIB. | REMARKS |
|------------------------|-----------|--------------|---------|----------------|------------------------------|---------|
| SLR DIGITAL CAMERA | NIKON | D50 | N/A | N/A | N/A | |
| TIRE PRESSURE GAUGE | WESKLER | 45-0/100 | 107 | 12 MO. | 04/03/10 | |
| INCLINOMETER | MITUTOYO | PRO 360 | 950-315 | N/A | BEFORE USE | |
| STEEL TAPE | STANLEY | FAT MAX | 33-890 | 12 MO. | 03/29/10 | |
| WHEEL SCALES | INTERCOMP | SERIES 94 | 199744 | 12 MO. | 03/02/11 | |
| WHEEL SCALES | INTERCOMP | SERIES 94 | 199744 | 12 MO. | 03/02/11 | |
| WHEEL SCALES | INTERCOMP | SERIES 94 | 199744 | 12 MO. | 03/02/11 | |
| WHEEL SCALES | INTERCOMP | SERIES 94 | 199744 | 12 MO. | 03/02/11 | |
| SPRING SCALE | CHATILLON | DPP-10 | 4729 | 12 MO. | BEFORE USE | |

PHOTOGRAPHS



FIGURE 5.1 ¾ FRONTAL VIEW FROM LEFT SIDE OF VEHICLE




FIGURE 5.2 VEHICLE CERTIFICATION LABEL

| | | EATING CAPACITY | TOTAL : 5 FRON | T: 2 REAR: 3 |
|---|-------|-----------------|--------------------|--------------|
| The combined weight of occupants : 430 kg or 950 lbs. | | | | |
| | TIRE | SIZE | COLD TIRE PRESSURE | SEE OWNERS |
| | FRONT | P255/45R19 | 220 KPA, 32 PSI | MANUAL FOR |
| | REAR | P255/45R19 | 220 KPA, 32 PSI | ADDITIONAL |
| | SPARE | T155/70D17 | 415 KPA, 60 PSI | INFORMATION |

FIGURE 5.3 VEHICLE TIRE INFORMATION LABEL



FIGURE 5.4 CLOSE-UP VIEW OF IGNITION KEY



FIGURE 5.5 START/STOP BUTTON ON DASH



FIGURE 5.6 ELECTRONIC KEY BACK-UP SLOT



FIGURE 5.7 ELECTRONIC KEY IN BACK-UP SLOT



FIGURE 5.8 NO KEY DETECTED WARNING



FIGURE 5.9 TRANSMISSION GEAR SELECTION CONTROL



FIGURE 5.10 GEAR SELECTOR RELEASE TOOL