REPORT NUMBER 114-GTL-09-008

SAFETY COMPLIANCE TESTING FOR FMVSS NO. 114 THEFT PROTECTION

MAZDA MOTOR CORPORATION 2009 MAZDA 3, PASSENGER CAR NHTSA NO. C95400

GENERAL TESTING LABORATORIES, INC. 1623 LEEDSTOWN ROAD COLONIAL BEACH, VIRGINIA 22443



July 20, 2009

FINAL REPORT

PREPARED FOR

U. S. DEPARTMENT OF TRANSPORTATION NATIONAL HIGHWAY TRAFFIC SAFETY ADMINISTRATION ENFORCEMENT OFFICE OF VEHICLE SAFETY COMPLIANCE 1200 NEW JERSEY AVE., SE WASHINGTON, D.C. 20590 This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturers' names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products or manufacturers.

Prepared By:	
Prepared By:	

Approved By:	
--------------	--

Approval Date: 07/20/09

FINAL REPORT ACCEPTANCE BY OXSC:
NC ON
Accepted By: MOUNCUS
- Catalla
Acceptance Date: $(/ - 1/ 0/ 0)$
- / // /

Technical Report Documentation Page

			lechn	ical Report Documentation Page		
1. Report No.	2. Government	Accessic	on No.	3. Recipient's Catalog No.		
114-GTL-09-008	N/A	۹		N/A		
4. Title and Subtitle				5. Report Date		
Final Report of FMV	•	nce Testi	ng of a	July 20, 2009		
2009 MAZDA 3 PAS				6. Performing Organ. Code		
NHTSA No. C95400				GTL		
7. Author(s)				8. Performing Organ. Rep#		
Grant Farrand, Proje				GTL-DOT-09-114-008		
Debbie Messick, Pro						
9. Performing Organ		d Addres	S	10. Work Unit No. (TRAIS)		
General Testing L				N/A		
1623 Leedstown				11. Contract or Grant No.		
Colonial Beach, V				DTNH22-06-C-00032		
12. Sponsoring Age		ddress		13. Type of Report and Period		
U.S. Department of				Covered		
National Highway Ti				Final Test Report		
Office of Vehicle Sa		(NVS-22)	0)	June 11, 2009		
1200 New Jersey Av				14. Sponsoring Agency Code		
Washington, DC 20	0590			NVS-221		
15. Supplementary Notes						
16. Abstract						
Compliance tests we	ere conducted on	the subj	ect 2009 Mazd	a 3 4-door passenger car in		
accordance with the specifications of the Office of Vehicle Safety Compliance Test						
Procedure No. TP-114-03-DRAFT-GTL-REVC for the determination of FMVSS 114						
compliance.						
Test failures identifie	ed were as follow	s:				
None						
17. Key Words			18. Distributio			
Compliance Testing				of this report are available from		
, , ,			NHTSA Technical Information Services (TIS)			
			-212 (NPO-411)			
		ersey Ave., S.E.				
Washington, DC 20590						
		04 11		b. (202) 366-4947		
19. Security Classif.		21. No.	of Pages	22. Price		
UNCLASSIFIED			25			
20. Security Classif.	· · · · /					
UNCLASSIFIED						
Form DOT F 1700.7	(Ö-/Z)					

Form DOT F 1700.7 (8-72)

TABLE OF CONTENTS

SECTION PAGE 1. Purpose of Compliance Test 1 2. Test Procedure and Summary of Results 2 3. Test Data 3 4. Test Equipment List 13 5. Photographs 14

5.1 ¾ Frontal View from Left Side of Vehicle

- 5.2 Vehicle Certification Label
- 5.3 Vehicle Tire Information Label
- 5.4 Close-up View of Ignition Key 5.5 Starting System Control
- 5.6 Transmission Gear Selection Control
- 5.7 Device which allows moving Gear Selector out of Park Position

PURPOSE OF COMPLIANCE TEST

1.0 PURPOSE OF TEST

A model year 2009 Mazda 3 passenger car was subjected to Federal Motor Vehicle Safety Standard (FMVSS) No. 114 testing to determine if the vehicle was in compliance with the requirements of the standard. FMVSS 114 specifies requirements to decrease the likelihood that a vehicle is stolen, or accidentally set in motion.

- 1.1 The test vehicle was a 2009 Mazda 3 Passenger Car. The vehicle was identified as follows:
 - A. Vehicle Identification Number: JM1BK323691232072
 - B. <u>NHTSA No.</u>: C95400
 - C. Manufacturer: MAZDA MOTOR CORPORATION
 - D. Manufacture Date: 09/08
 - E. <u>Color</u>: Sunlight Silver Metallic

1.2 TEST DATE

The test vehicle was subjected to FMVSS No. 114 testing on June 11, 2009.

TEST PROCEDURE AND SUMMARY OF RESULTS

2.0 <u>TEST PROCEDURE</u>

All tests were conducted in accordance with NHTSA, Office of Vehicle Safety Compliance (OVSC) Laboratory Procedure TP-114-03-DRAFT-GTL-REVC and General Testing Laboratories, Inc. (GTL) Test Procedure, TP-114-03-Draft, "Theft Protection and Rollaway Prevention".

2.1 <u>SUMMARY OF RESULTS</u>

Test data indicate the FMVSS 114 requirements appear to have been satisfied. All test data resulting from the tests were recorded on test data sheets in Section 3.

TEST DATA

3.0 TEST RESULTS

The following data sheets document the results of FMVSS 114 testing on the 2009 Mazda 3.

FMVSS 114, THEFT PROTECTION DATA SHEET 1 – VEHICLE IDENTIFICATION

TEST DATE: <u>06/11/09</u> CONTRACT: <u>DTNH22-06-C-00032</u> VIN: <u>JM1BK323691232072</u>	LAB.: <u>General Testing Laboratories</u> VEH. NHTSA NO.: <u>C95400</u> BUILD DATE: <u>09/08</u>
MY/MAKE/MODEL/BODY STYLE: 2009 Mazo	la 3
TRANSMISSION TYPE: Automatic <u>X</u> ; Manual; Other (de	scribe:)
DRIVE TRAIN TYPE: Front Wheel; Rear Wheel	_; 4-Wheel
FUEL TANK LEVEL: <u>100</u> (% OF max.) MILEAGE: <u>670</u>
VEHICLE STARTING SYSTEM:	
Location of the starting system: On Right Side of Steering Column	
Selectable settings: Lock, Accessory, On/Run, Start	
Explain how the system is activated: Insert key into key slot and turn clockwis	Se
KEY	
Description of the key: Traditional Key with built in code	
STARTING SYSTEM ACTIVATION	
Describe how the key is inserted into the startin Insert key into key slot	ng system:
Describe how the key is used to activate the st Turn key clockwise	arting system:

Describe how the key is removed from the starting system: Turn key to off/lock position and pull out

FMVSS 114, THEFT PROTECTION DATA SHEET 1 continued

GEAR SELECTION CONTROL

Describe the gear selection control: Center Console mounted Gear Shift Lever

Describe how the gear selection control is activated: Press and hold brake while moving gear selector to desired position

Describe all of the selectable settings: Park, Reverse, Neutral, Drive, Manual

IMMOBILIZER

Is the vehicle equipped with an immobilizer YES X NO_____

Describe the immobilizer device and how it prevents vehicle theft (if equipped): Code embedded in key. Engine will not start with an unrecognized key

OPTIONAL RELEASE DEVICES

Describe if the vehicle is equipped with optional release devices: Yes for shifter

OPTIONAL RELEASE DEVICES:

Key	Removal	Gear Selection Control	Х	None	Other
-----	---------	------------------------	---	------	-------

VEHICLE FLUIDS

Check all vehicle fluids and adjust to the proper levels for operation: Full

VEHICLE TIRE PLACARD INFORMATION

Vehicle Mfg. Recommended Tire Inflation Pressure (kPa): Front 220 Rear 220

TIRE INFLATION PRESSURES:

Measured (kPa): LF 220 LR 220 RF 220 RR 220

<u>WEIGHT</u>

Vehicle Curb Weight(kg): <u>1348</u> Weight of Driver (kg): <u>91</u> (target = 91kg)

FMVSS 114, THEFT PROTECTION DATA SHEET 2

REQUIREMENT S5.1.1				FAIL	
Engine cannot be started without using the key X	Yes	No	Х		
With key removed, steering wheel locks: Yes: <u>X</u> No:					
Identify locking position(s) on wheel using arrow(s)					
Clockwise: <u>8</u> (degrees) Counterclockwise: <u>15</u> (degrees)				/ 	
Key removal prevents forward self-mobility: Y	'es:	Х	No:	_	
If yes describe: Vehicle will not start without key in vehicle and the steering locks. When key is removed from the starting system, starting of the engine or motor and either steering or self mobility is prevented. YES X					
		•			

FMVSS 114, THEFT PROTECTION DATA SHEET 2 continued

REQUIREMENT S5.1.3		FAIL
An audible warning is activated whenever the key is in any starting system position with the exception of "on" and "start" and the door closest to the driver's designated seating position is opened. Yes <u>X</u> No	x	
Identify ALL key/starting system position setting: Lock, Accessory, On/Run, Start		

REQUIREMENT S5.1.4	PASS	FAIL
With the vehicle engine or motor shut down and the transmission gear selection control in any position other than "park"; The steering wheel can rotate without locking? Yes X No	x	
The vehicle is free to roll forward? Yes <u>X</u> No	x	

REMARKS:

RECORDED BY: <u>G. Farrand</u> APPROVED BY: <u>D. Messick</u> DATE: 06/11/09

FMVSS 114, ROLLAWAY PREVENTION DATA SHEET 3 (for vehicles equipped with transmission with a "park" position)

TEST DATE: 06/11/09

(ior venicles equipped with transmission with a par

VEH. NHTSA NO.: C95400

REQUIREMENT S5.2.1	PASS	FAIL
The starting system prevents key removal in ALL gear selection control positions except "park". Yes <u>X</u> No	х	
Can the gear selection control be placed between each gear selection position and will it remain there without assistance? Yes NoX		
If yes, can the key be removed from the starting system? Yes No	х	
If the key can be removed from the vehicle starting system when the gear selection control is not locked in "park", a mechanism shall exist which, upon key removal, the vehicle transmission or gear selection control shall become locked in "park" as the direct result of removing the key. If such a mechanism exists, describe the mechanism and its function:		

REQUIREMENT S5.2.2		FAIL
The gear selection control is locked in the "park" position when the key is removed from the starting system. Yes <u>X</u> No	х	

REQUIREMENT S5.2.3	PASS	FAIL
ELECTRICAL FAILURE (Battery Discharge)		
In the event of an electrical failure, key removal from the starting system when the transmission or gear selection control is not locked in "park" is permitted". Yes NoX	Х	
The vehicle is equipped with an override device that permits key removal from the starting system when the transmission or gear selection control is not locked in "park". Yes NoX	Х	
If yes, select the type of override device equipped: Opaque Cover No Cover	N/A	
Describe the override device design and mode of activation (if equipped):		
FILL IN THE SECTION BELOW THAT APPLIES:		
OVERRIDE WITH AN OPAQUE COVER:		
The opaque surface cover prevents sight of and use of override device. Yes No		
The opaque surface cover can only be removed by using a screwdriver or other tool. Yes No	N/A	
As a direct result of removing the key from starting system, the following is prevented: Steering or Self-Mobility		
OVERRIDE WITH NO COVER		
The override device requires the use of a tool to activate. Yes No		
Simultaneous activation of the override device and removal of key from starting system is required. YesNo	N/A	
As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility		

REQUIREMENT S5.2.4	PASS	FAIL
GEAR SELECTION CONTROL OVERRIDE DEVICE		
The vehicle is equipped with an override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. Yes X No		
If yes, select the type of override device that is equipped: Override operated with a: Key Opaque Cover X_ No Cover	Х	
Describe the override device design and mode of activation (if equipped): Remove cover on shifter housing and insert screwdriver and push down		
FILL IN THE SECTION BELOW THAT APPLIES:		
OVERRIDE OPERATED WITH KEY:		
The key is required to operate the override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. Yes No	N/A	
OVERRIDE WITH AN OPAQUE COVER		
The opaque surface cover prevents sight of and use of override device. Yes <u>X</u> No		
The opaque surface cover can only be removed by using a screwdriver or other tool. Yes <u>X</u> No	Х	
As a direct result of removing the key from the starting system, the following is prevented: Steering X or Self-Mobility	~	
OVERRIDE WITH NO COVER		
The override device requires the use of a tool to operate. Yes No		
Simultaneous activation of the override device and removal of key from starting system is required. Yes No	N/A	
As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility		

REQUIREMENTS S5.2.5	PASS	FAIL
VEHICLE FACING UPHILL ON 10% GRADE		
With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake.		see note
Test grade: <u>15</u> % (9% to 15%) Measured movement: <u>42</u> mm (150mm maximum)	Х	
NOTE: Repeat procedure if vehicle fails on grade in excess of 10%.		
Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum)		
VEHICLE FACING DOWNHILL ON 10% GRADE		
With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake.		
Test grade: <u>15</u> % (9% to 15%) Measured movement: <u>45</u> mm (150mm maximum)	х	
NOTE: Repeat procedure if vehicle fails on grade in excess of 10%.		
Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum)		

REQUIREMENTS S5.3	PASS	FAIL
VEHICLE FACING UPHILL ON 10% GRADE		
With the key in the "off" position, the transmission will shift out of "park" without the service brake being applied. Yes NoX	<u>X</u>	
With the key in the "acc" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X	<u> </u>	
With the key in the "on" position (engine off), the transmission will shift out of "park" without the service brake being applied. Yes NoX	<u> </u>	
With the key in the "start" position, the transmission will shift out of "park" without the service brake being applied. Yes NoX	<u> </u>	
With the key in the "other" position (please specify), the transmission will shift out of "park" without the service brake being applied. Yes NoX	x	
Does the key stay between starting system positions without being held by operator? Yes NoX If so, please describe.	<u> x </u>	
Brake force readings (force required to allow the transmission to shift out of "park"):		
The vehicle is equipped with adjustable pedals: Yes NoX		
Fore Position: Aft Position (if applicable)		
Reading 1 23.1 N Reading 1 Reading 2 24.4 N Reading 2 Reading 3 22.2 N Reading 3 Reading 4 22.2 N Reading 4 Reading 5 22.7 N Reading 5 Avg. 22.9 N Avg.	<u> </u>	

RECORDED BY:	G. Farrand	DATE:	06/11/09
APPROVED BY:	D. Messick		

SECTION 4 TEST EQUIPMENT LIST

ITEM	MFR	MODEL	S/N	CAL. PERIOD	DATE OF NEXT CALIB.	REMARKS
SLR DIGITAL CAMERA	NIKON	D50	N/A	N/A	N/A	
TIRE PRESSURE GAUGE	WESKLER	45-0/100	107	12 MO.	03/10	
INCLINOMETER	MITUTOYO	PRO 360	950-315	N/A	BEFORE USE	
STEEL TAPE	STANLEY	FAT MAX	33-890	12 MO.	03/10	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	04/10	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	04/10	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	04/10	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	04/10	
SPRING SCALE	CHATILLON	DPP-10	4729	12 MO.	04/10	

PHOTOGRAPHS



FIGURE 5.1 ¾ FRONTAL VIEW FROM LEFT SIDE OF VEHICLE



FIGURE 5.2 VEHICLE CERTIFICATION LABEL

R	TIRE	AND LOADING	INFORMATIO
			FRONT 2 REAR 3
The combin	ed weight of occup	ants and cargo should ne	ever exceed 385kg or 850
TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S
FRONT	P205/50R17	220KPA, 32PSI	MANUAL FOR
REAR	P205/50R17	220KPA, 32PS1	ADDITIONAL
SPARE	T125/70D16	420KPA, 60PS1	INFORMATION

FIGURE 5.3 VEHICLE TIRE INFORMATION LABEL





FIGURE 5.5 STARTING SYSTEM CONTROL



FIGURE 5.6 TRANSMISSION GEAR SELECTION CONTROL



FIGURE 5.7 DEVICE WHICH ALLOWS MOVING GEAR SELECTOR OUT OF PARK POSITION