SAFETY COMPLIANCE TESTING FOR FMVSS NO. 114 THEFT PROTECTION

NISSAN MOTOR CO., LTD. 2010 INFINITI G37, PASSENGER CAR NHTSA NO. CA5204

GENERAL TESTING LABORATORIES, INC. 1623 LEEDSTOWN ROAD COLONIAL BEACH, VIRGINIA 22443



June 21, 2010

FINAL REPORT

PREPARED FOR

U. S. DEPARTMENT OF TRANSPORTATION
NATIONAL HIGHWAY TRAFFIC SAFETY ADMINISTRATION
ENFORCEMENT
OFFICE OF VEHICLE SAFETY COMPLIANCE
1200 NEW JERSEY AVE., SE
WASHINGTON, D.C. 20590

This publication is distributed by the U.S. Department of Transportation, National Highway Traffic Safety Administration, in the interest of information exchange. The opinions, findings and conclusions expressed in this publication are those of the author(s) and not necessarily those of the Department of Transportation or the National Highway Traffic Safety Administration. The United States Government assumes no liability for its contents or use thereof. If trade or manufacturers' names or products are mentioned, it is only because they are considered essential to the object of the publication and should not be construed as an endorsement. The United States Government does not endorse products or manufacturers.

Prepared By:	
Approved By:	
Approval Date:	06/21/10

FINAL REPORT ACCEPTANCE BY OVSC:

Accepted By:

Acceptance Date:

Technical Report Documentation Page				
1. Report No. 2. Government Accession No. 3. Recipient's Catalog No.				
114-GTL-10-008	N/A	N/A		
4. Title and Subtitle		5. Report Date		
Final Report of FMV	SS 114 Compliance Testing of a	June 21, 2010		
2010 INFINITI G37 I		6. Performing Organ. Code		
NHTSA No. CA5204		GTL		
7. Author(s)		8. Performing Organ. Rep#		
Grant Farrand, Proje	<u> </u>	GTL-DOT-10-114-008		
Debbie Messick, Pro	oject Manager			
0 0	ization Name and Address	10. Work Unit No. (TRAIS)		
General Testing L	•	N/A		
1623 Leedstown I	Road	11. Contract or Grant No.		
Colonial Beach, V	a 22443	DTNH22-06-C-00032		
	ncy Name and Address	13. Type of Report and Period		
U.S. Department of		Covered		
0 1	affic Safety Admin. Enforcement	Test Date		
	fety Compliance (NVS-220)	March 26, 2010		
1200 New Jersey Av	/e., S.E.,	14. Sponsoring Agency Code		
Washington, DC 20)590	NVS-221		
15. Supplementary I	Notes			

16. Abstract

Compliance tests were conducted on the subject 2010 Infiniti G37 4-door Passenger Car in accordance with the specifications of the Office of Vehicle Safety Compliance Test Procedure No. TP-114-03-DRAFT-GTL-REVC for the determination of FMVSS 114 compliance.

Test failures identified were as follows:

None

17. Key Words Compliance Testing Safety Engineering FMVSS 114	Copies of to NHTSA Te Room W48 1200 New Washington	ution Statement this report are available from echnical Information Services (TIS) 5-212 (NPO-411) Jersey Ave., S.E. on, DC 20590 e No. (202) 366-4947
19. Security Classif. (of this report) UNCLASSIFIED	21. No. of Pages 30	22. Price
20. Security Classif. (of this page) UNCLASSIFIED		

Form DOT F 1700.7 (8-72)

TABLE OF CONTENTS

SECTION	PAGE
 Purpose of Compliance Test Test Procedure and Summary of Results Test Data Test Equipment List Photographs 	1 2 3 14 15
 5.1 ¾ Frontal View from Left Side of Vehicle 5.2 Vehicle Certification Label 5.3 Vehicle Tire Information Label 5.4 Close-up View of Electronic Ignition Key 5.5 Start/Stop Button on Dash 5.6 Key FOB Intelliport 5.7 Key FOB in Intelliport 5.8 No Key Warning on Dash 5.9 Transmission Gear Selection Control 5.10 Cover over Gear Selector Release 5.11 Gear Selector Release Tool 	

PURPOSE OF COMPLIANCE TEST

1.0 PURPOSE OF TEST

A model year 2010 Infiniti G37 Passenger Car was subjected to Federal Motor Vehicle Safety Standard (FMVSS) No. 114 testing to determine if the vehicle was in compliance with the requirements of the standard. FMVSS 114 specifies requirements to decrease the likelihood that a vehicle is stolen, or accidentally set in motion.

- 1.1 The test vehicle was a 2010 Infiniti G37 Passenger Car. The vehicle was identified as follows:
 - A. Vehicle Identification Number: JN1CV6AR7AM454290
 - B. NHTSA No.: CA5204
 - C. Manufacturer: NISSAN MOTOR CO., LTD.
 - D. Manufacture Date: 12/09
 - E. Color: White

1.2 TEST DATE

The test vehicle was subjected to FMVSS No. 114 testing on March 26, 2010.

TEST PROCEDURE AND SUMMARY OF RESULTS

2.0 <u>TEST PROCEDURE</u>

All tests were conducted in accordance with NHTSA, Office of Vehicle Safety Compliance (OVSC) Laboratory Procedure TP-114-03-DRAFT-GTL-REVC and General Testing Laboratories, Inc. (GTL) Test Procedure, TP-114-03-Draft, "Theft Protection and Rollaway Prevention".

2.1 <u>SUMMARY OF RESULTS</u>

Test data indicate the FMVSS 114 requirements appear to have been satisfied. All test data resulting from the tests were recorded on test data sheets in Section 3.

TEST DATA

3.0 <u>TEST RESULTS</u>

The following data sheets document the results of FMVSS 114 testing on the 2010 Infiniti G37.

FMVSS 114, THEFT PROTECTION DATA SHEET 1 – VEHICLE IDENTIFICATION

CONTRACT: 03/26/10 CONTRACT: DTNH22-06-C-00032	VEH. NHTSA NO.: <u>CA5204</u>
VIN: JN1CV6AR7AM454290 MY/MAKE/MODEL/BODY STYLE: 2010 Infinit	BUILD DATE: <u>12/09</u>
TRANSMISSION TYPE: Automatic X; Manual; Other	(describe:)
DRIVE TRAIN TYPE: Front Wheel; Rear Wheel	_; 4-Wheel <u>X</u>
FUEL TANK LEVEL: 100 (% OF max.)	MILEAGE: <u>136.5</u>
VEHICLE STARTING SYSTEM:	
Location of the starting system: Located on Dash to the Right Side of Steering	Column
Selectable settings: Lock/Off, Accessory, On, Start	
Explain how the system is activated: For the automatic transmission, with the KEY F system is actuated and the electronic code mat button is pushed with the brake pedal depresse position.	cching process starts when the start/stoped and the shifter is in the park or neutral
<u>KEY</u>	
Description of the key: Electronic Key FOB, (I-KEY system) with	n embedded code

STARTING SYSTEM ACTIVATION

Describe how the key is inserted into the starting system:

The electronic code is inserted into the starting system when the FOB is inside the vehicle and the operator pushes the push-button ignition switch(start/stop). Specifically, the electronic code is inserted into the vehicle's I-KEY system when ID verification to the key FOB is determined valid.

Describe how the key is used to activate the starting system:

Once the electronic code is in the starting system, the engine is activated and deactivated by pressing the start/stop button. In automatic transmission vehicles, the brake pedal must be depressed to start the engine.

FMVSS 114, THEFT PROTECTION DATA SHEET 1 continued

Describe how the key is removed from the starting system:

For an automatic transmission vehicle, the electronic code is removed from the vehicle's starting system only, when (1) the engine is shut off; and (2) the transmission is in the "park" position.

GEAR SELECTION CONTROL
Describe the gear selection control: <u>Center Console Mounted Gear Selector.</u>
Describe how the gear selection control is activated: <u>Depress on Brake Pedal then move gear selector to desired position.</u>
Describe all of the selectable settings: Park, Reverse, Neutral, Drive with ±
<u>IMMOBILIZER</u>
Is the vehicle equipped with an immobilizer YES X NO
Describe the immobilizer device and how it prevents vehicle theft (if equipped): The electronic code is inserted into the vehicle's I-Key system when ID verification to the Key is determined valid. Once the electronic code is in the starting system, the engine is Activated and deactivated by pressing the start/stop button. OPTIONAL RELEASE DEVICES
Describe if the vehicle is equipped with optional release devices: Yes
OPTIONAL RELEASE DEVICES:
Key Removal Gear Selection ControlX None Other
VEHICLE FLUIDS
Check all vehicle fluids and adjust to the proper levels for operation: Full
VEHICLE TIRE PLACARD INFORMATION
Vehicle Mfg. Recommended Tire Inflation Pressure (kPa): Front 230 Rear 230

FMVSS 114, THEFT PROTECTION DATA SHEET 1 continued

TIRE INFLATION PRESSURES:

Measured (kPa): LF 230 LR 230 RF 230 RR 230

WEIGHT

Vehicle Curb Weight(kg): 1741 Weight of Driver (kg): 91 (target = 91kg)

FMVSS 114, THEFT PROTECTION DATA SHEET 2

REQUIREMENT S5.1.1		FAIL
Engine cannot be started without using the key X YesNo	X	
With key removed, steering wheel locks: Yes: X No:		
Note: After opening driver door	\	
Identify locking position(s) on wheel using arrow(s)	0 66	,
Clockwise: 0 (degrees) Counterclockwise: 340 (degrees)		<u> </u>
Key removal prevents forward self-mobility: Yes: X No	<u> </u>	_
If yes describe: Vehicle will not start without key.		
When key is removed from the starting system, starting of the engine or motor and either steering or self mobility is prevented. YES	Х	

REMARKS:

FMVSS 114, THEFT PROTECTION DATA SHEET 2 continued

REQUIREMENT S5.1.3	PASS	FAIL
An audible warning is activated whenever the key is in any starting system position with the exception of "on" and "start" and the door closest to the driver's designated seating position is opened. Yes X No	Х	
Note:		
Identify ALL key/starting system position setting: LOCK/OFF, ACCESSORY, ON, START		

REQUIREMENT S5.1.4		FAIL
With the vehicle engine or motor shut down and the transmission gear selection control in any position other than "park";	X	
The steering wheel can rotate without locking? Yes_X No		
NOTE: Engine cannot be turned off by push button if gear selector is not in the park position.		
The vehicle is free to roll forward? Yes_X_ No	Х	

REMARKS:

RECORDED BY: G. Farrand DATE: 03/26/10

APPROVED BY: D. Messick

FMVSS 114, ROLLAWAY PREVENTION DATA SHEET 3

(for vehicles equipped with transmission with a "park" position)

VEH. NHTSA NO.:	CA5204	TEST DATE:	03/26/10

REQUIREMENT S5.2.1	PASS	FAIL
The starting system prevents key removal in ALL gear selection control positions except "park". Yes X No		
Can the gear selection control be placed between each gear selection position and will it remain there without assistance? Yes No_X	X	
If yes, can the key be removed from the starting system? Yes No		
If the key can be removed from the vehicle starting system when the gear selection control is not locked in "park", a mechanism shall exist which, upon key removal, the vehicle transmission or gear selection control shall become locked in "park" as the direct result of removing the key. If such a mechanism exists, describe the mechanism and its function:		

REQUIREMENT S5.2.2	PASS	FAIL
The gear selection control is locked in the "park" position when the key is removed from the starting system. Yes X No	Х	

REMARKS:

REQUIREMENT S5.2.3	PASS	FAIL
ELECTRICAL FAILURE (Battery Discharge)		
In the event of an electrical failure, key removal from the starting system when the transmission or gear selection control is not locked in "park" is permitted". Yes X No		
The vehicle is equipped with an override device that permits key removal from the starting system when the transmission or gear selection control is not locked in "park".		
Yes No <u>X</u>		
If yes, select the type of override device equipped: Opaque Cover No Cover	N/A	
Describe the override device design and mode of activation (if equipped):		
FILL IN THE SECTION BELOW THAT APPLIES:		
OVERRIDE WITH AN OPAQUE COVER:		
The opaque surface cover prevents sight of and use of override device. Yes No		
The opaque surface cover can only be removed by using a screwdriver or other tool. Yes No	N/A	
As a direct result of removing the key from starting system, the following is prevented: Steering or Self-Mobility		
OVERRIDE WITH NO COVER		
The override device requires the use of a tool to activate. Yes No		
Simultaneous activation of the override device and removal of key from starting system is required. Yes No	N/A	
As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility		

REMARKS:

REQUIREMENT S5.2.4	PASS	FAIL
GEAR SELECTION CONTROL OVERRIDE DEVICE		
The vehicle is equipped with an override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. Yes_X_ No		
If yes, select the type of override device that is equipped: Override operated with a: Key Opaque Cover_X No Cover		
Describe the override device design and mode of activation (if equipped): Push button release activated by a special wrench supplied in tool kit.		
FILL IN THE SECTION BELOW THAT APPLIES:		
OVERRIDE OPERATED WITH KEY:		
The key is required to operate the override device that allows the user to move the gear selection control from "park" after the key has been removed from the starting system. Yes No	N/A	
OVERRIDE WITH AN OPAQUE COVER		
The opaque surface cover prevents sight of and use of override device. Yes_X No		
The opaque surface cover can only be removed by using a screwdriver or other tool. Yes X No	X	
As a direct result of removing the key from the starting system, the following is prevented: Steering X or Self-Mobility X		
OVERRIDE WITH NO COVER		
The override device requires the use of a tool to operate. Yes No		
Simultaneous activation of the override device and removal of key from starting system is required. Yes No	N/A	
As a direct result of removing the key from the starting system, the following is prevented: Steering or Self-Mobility		

REQUIREMENTS S5.2.5	PASS	FAIL
VEHICLE FACING UPHILL ON 10% GRADE		
With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake.		see note
Test grade: % (9% to 15%) Measured movement: mm (150mm maximum)	X	
NOTE: Repeat procedure if vehicle fails on grade in excess of 10%.		
Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum)		
VEHICLE FACING DOWNHILL ON 10% GRADE		
With the gear selection control in "park" measure movement of the vehicle down the slope upon releasing the service brake.		
Test grade:% (9% to 15%) Measured movement: mm (150mm maximum)	Х	
NOTE: Repeat procedure if vehicle fails on grade in excess of 10%.		
Test grade: % (9% to 10%) Measured movement: mm (150 mm maximum)		

REMARKS:

REQUIREMENTS S5.3	PASS	FAIL
VEHICLE FACING UPHILL ON 10% GRADE		
With the key in the "off" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X	<u>x</u>	
With the key in the "acc" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X	<u>x</u>	
With the key in the "on" position (engine off), the transmission will shift out of "park" without the service brake being applied. Yes No_ X	<u>x</u>	
With the key in the "start" position, the transmission will shift out of "park" without the service brake being applied. Yes No_X	<u>x</u>	
With the key in the "other" position (please specify), the transmission will shift out of "park" without the service brake being applied. Yes No	_N/A	
Does the key stay between starting system positions without being held by operator? Yes No_X If so, please describe.		
Brake force readings (force required to allow the transmission to shift out of "park"):		
The vehicle is equipped with adjustable pedals: Yes No X		
Fore Position: Aft Position (if applicable)		
Reading 1 3.9 N Reading 1 Reading 2 3.9 N Reading 2 Reading 3 3.8 N Reading 3 Reading 4 3.8 N Reading 4 Reading 5 3.9 N Reading 5 Avg. 3.86 N Avg.	<u>x</u>	
DEMARKS:		

REMARKS:		
RECORDED BY: _ APPROVED BY: _	DATE:	03/26/10

SECTION 4 TEST EQUIPMENT LIST

ITEM	MFR	MODEL	S/N	CAL. PERIOD	DATE OF NEXT CALIB.	REMARKS
SLR DIGITAL CAMERA	NIKON	D50	N/A	N/A	N/A	
TIRE PRESSURE GAUGE	WESKLER	45-0/100	107	12 MO.	04/03/10	
INCLINOMETER	MITUTOYO	PRO 360	950-315	N/A	BEFORE USE	
STEEL TAPE	STANLEY	FAT MAX	33-890	12 MO.	03/29/10	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	03/02/11	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	03/02/11	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	03/02/11	
WHEEL SCALES	INTERCOMP	SERIES 94	199744	12 MO.	03/02/11	
SPRING SCALE	CHATILLON	DPP-10	4729	12 MO.	BEFORE USE	

PHOTOGRAPHS



NHTSA NO. CA5204 FMVSS NO. 114

FIGURE 5.1 3/4 FRONTAL VIEW FROM LEFT SIDE OF VEHICLE

MANUFACTURED BY NISSAN MOTOR CO., LTD.

DATE: 12/09

GVWR/PNBV: 4846 LBS.

GAWR/PNBE FR: 2423 LBS. RR: 2482 LBS.

THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY, BUMPER, AND THEFT PREVENTION STANDARDS IN EFFECT ON THE DATE OF MANUFACTURE

SHOWN ABOVE.

VIN: JN1CV6AR7AM454290

PASSENGER CAR

COLOR TRIM TRANS AXLE ENGINE

QAA K RE7R01A RC33 VQ37(VHR) 3696CC



JN1CV6AR7AM454290




FIGURE 5.3 VEHICLE TIRE INFORMATION LABEL



NHTSA NO. CA5204 FMVSS NO. 114

FIGURE 5.4 CLOSE-UP VIEW OF IGNITION KEY



FIGURE 5.5 START/STOP BUTTON ON DASH



FIGURE 5.6 KEY FOB INTELLIPORT



FIGURE 5.7 KEY FOB IN INTELLIPORT



FIGURE 5.8 NO KEY WARNING ON DASH



2010 INFINITI G37 NHTSA NO. CA5204 FMVSS NO. 114

FIGURE 5.9 TRANSMISSION GEAR SELECTION CONTROL



FIGURE 5.10 COVER OVER GEAR SELECTOR RELEASE



FIGURE 5.11 GEAR SELECTOR RELEASE TOOL